



CHAOSFAB.COM

INSTALLATION INSTRUCTIONS


UNIBALL UPPER CONTROL ARMS

TC-96504

DATE: 4.9.19
REV: 03
SCALE: N.T.S.
PAGE: 1 OF 4
DRAWN: CM

INSTALLATION DRAWINGS ARE FOR THE:

- 2005+ TACOMA PRERUNNER & 4WD
- 2003+ 4RUNNER
- 2007+ FJ CRUISER
- 2003-2009 GX 470
- 2010+ GX 460
- 2005-2015 HILUX VIGO
- 2016+ HILUX REVO
- 2003-2009 PRADO 120
- 2010+ PRADO 150
- 2005+ FORTUNER



PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF TOTAL CHAOS FABRICATION. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF TOTAL CHAOS FABRICATION IS PROHIBITED.

*LEFT SIDE OF TRUCK SHOWN. SOME ITEMS NOT SHOWN FOR CLARITY



CHAOSFAB.COM


INSTALLATION INSTRUCTIONS

UNIBALL UPPER CONTROL ARMS

TC-96504

DATE: 4.9.19
REV: 03
SCALE: N.T.S.
PAGE: 2 OF 4
DRAWN: CM

ZERK FITTING HOLES ARE TAPPED 1/4"-28.
IF THE POWDERCOAT BUILDUP IS MAKING
INSTALLATION DIFFICULT RUN A 1/4"-28
TAP THROUGH THE HOLE.



APPLY GENEROUS AMOUNTS OF GREASE TO OUTSIDE OF SLEEVES, OUTER FACE OF URETHANE BUSHINGS & I.D. OF URETHANE BUSHINGS.

REMOVE THE STOCK METAL BRACKET FROM THE ABS WIRE BEFORE SECURING IT TO THE TAB ON THE REAR TUBE OF THE UCA USING A ZIP-TIE.

PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF TOTAL CHAOS FABRICATION. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF TOTAL CHAOS FABRICATION IS PROHIBITED.

*LEFT SIDE OF TRUCK SHOWN. SOME ITEMS NOT SHOWN FOR CLARITY


INSTALLATION INSTRUCTIONS

UNIBALL UPPER CONTROL ARMS

TC-96504

DATE: 4.9.19
REV: 03
SCALE: N.T.S.
PAGE: 3 OF 4
DRAWN: CM


ZERK FITTING HOLES ARE TAPPED 1/4"-28.
IF THE POWDERCOAT BUILDUP IS MAKING
INSTALLATION DIFFICULT RUN A 1/4"-28
TAP THROUGH THE HOLE.




IMPORTANT NOTE

During assembly, upper & lower spacers are specific. Failure to follow these instructions will result in damage of all components.

Upper spacer has 9/16" hole



Upper spacer has 3/4" hole



WHEN ROTATING THE UCA DOWN TO MATE UP TO THE SPINDLE, ENSURE THE HI-MISALIGNMENT SPACERS STAY FULLY SEATED IN THE UNIBALL. DAMAGE MAY OCCUR IF THEY ARE ONLY PARTIALLY SEATED WHILE THE UNIBALL BOLT IS BEING TIGHTENED.

PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF TOTAL CHAOS FABRICATION. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF TOTAL CHAOS FABRICATION IS PROHIBITED.

*LEFT SIDE OF TRUCK SHOWN. SOME ITEMS NOT SHOWN FOR CLARITY

INSTALLATION INSTRUCTIONS

UNIBALL UPPER CONTROL ARMS

TC-96504

DATE: 4.9.19
 REV: 03
 SCALE: N.T.S.
 PAGE: 4 OF 4
 DRAWN: CM

INSTALLATION NOTES

- THE FACTORY MANUAL IS REQUIRED FOR TORQUE SPECIFICATIONS ON ALL FACTORY HARDWARE. THIS PROCEDURE WILL INVOLVE THE REMOVAL AND RE-INSTALLATION OF MANY PARTS. ALWAYS USE FACTORY REPLACEMENTS FOR WORN OR DAMAGED PARTS
- SOME ITEMS ARE NOT SHOWN FOR CLARITY
- PAGE 2
 APPLY GENEROUS AMOUNTS OF GREASE TO OUTSIDE OF SLEEVES, OUTER FACE OF URETHANE BUSHINGS & I.D. OF URETHANE BUSHINGS
- PAGE 3
 TORQUE ITEM #6 TO 100 FT/LBS
- INSPECT ALL COMPONENTS AND RE-TORQUE ALL HARDWARE WITHIN 500 MILES

TOTAL CHAOS FABRICATION
 159 N. MAPLE ST. UNIT J
 CORONA, CA 92880
 951.737.9682

PARTS LIST: TC-96504 UPPER CONTROL ARM


ITEM #	PART #	QTY	ITEM DESCRIPTION
1	99654L	1	LEFT UPPER CONTROL ARM
	99654R	1	RIGHT UPPER CONTROL ARM
2	60684	8	BUSHING - URETHANE HALF
3	69120	4	INNER SLEEVE
4	10005	4	FITTING - GREASE (ZERK)
5	69620	8	WASHER - PLATED PIVOT END
6	10251	2	BOLT - 9/16" x 5.00L
7	12203	2	WASHER - 9/16" AN
8	100916	2	SPACER - 9/16" MISALIGNMENT
9	10034-TCF	2	SPACER - 3/4" MISALIGNMENT
10	30004	2	ADAPTER - 9/16" TAPERED SPINDLE ADAPTER
11	12204	2	WASHER - 9/16" SAE
12	11202	2	NUT - 9/16" C-LOCK

PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF TOTAL CHAOS FABRICATION. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF TOTAL CHAOS FABRICATION IS PROHIBITED.

*LEFT SIDE OF TRUCK SHOWN. SOME ITEMS NOT SHOWN FOR CLARITY

UPPER CONTROL ARM HARDWARE ASSEMBLY ORDER



PRIOR TO ASSEMBLY, PLEASE NOTE:

- Items 3, 4 and 5 are pre-installed in the UCA.
- Items 1-6 go above the spindle.
- Item 3 has a 9/16" inner diameter (ID) and item 5 has a 3/4" ID. It is critical the 3/4" ID goes on the bottom so the straight side of the tapered spindle adapter #6 properly registers inside it.
- The tapered spindle adapter #6 goes into the top of the spindle with the tapered side down to ensure proper fitment.
- A spare zerk fitting is supplied with this kit.
- Complete installation instructions available at www.chaosfab.com/install.



HOW TO GREASE TOTAL CHAOS POLYURETHANE BUSHINGS

Polyurethane bushings are prone to squeaking and have the potential of making slight noise even if maintained properly. The reason TOTAL CHAOS uses polyurethane is that it is far stronger and has much less flex than stock rubber bushings. TOTAL CHAOS recommends using Super Lube® Part Number 41150 (or an equivalent PTFE marine grade water proof grease). Avoid using lubricants such as white lithium, any type of penetrant, or spray style lubricant.

STEP 1

Using a mallet, install the dry bushings into the control arm pivots.



STEP 2

With the bushings installed in the control arm, generously apply grease to the inner diameter of the bushings trying to fill the bushing grooves completely with grease.



STEP 3

Generously grease the outer diameter of the supplied TC metal inner sleeves.

**STEP 4**

Using a mallet, arbor press, or smooth jawed vise, install the metal inner sleeve into the bushing.



STEP 5

Using the excess grease, use your finger or a small brush to lubricate the outsides or “hats” of the bushings where they make contact with the plated end washers or control arm pocket.



STEP 6

When installing the zerk fittings, it may be necessary to use a knife or sharp object to clean out the top of the threaded hole so the $\frac{1}{4}$ "-28 NTP threads will catch. When tightening the zerk, DO NOT try and tighten the zerk to the bottom of the thread. It is only necessary to turn the zerk until it gets snug. Then rotate as far as necessary to make the fitting accessible for a grease gun.



ONGOING BUSHING MAINTENANCE

NOTE: The following procedure is applicable to most modern Toyotas and vehicles that utilize our zinc plated end washers on both sides of the pivot bushings. This procedure DOES NOT apply to the following:

- 1998-2007 Land Cruiser 100 Series
- Mitsubishi Montero
- All Ford F150s and Raptors
- All Chevrolet/GMC models
- All Dodge models
- All Nissan models

If you are unsure of the correct procedure to properly grease your bushings, please contact us by calling 951-737-9682 or emailing info@chaosfab.com.

To maximize performance and the lifespan of your polyurethane bushings, some maintenance is required. TOTAL CHAOS recommends greasing your bushings every 5,000 miles (similar to an oil change interval). Greasing more frequently may be required if the vehicle sees dirt and adverse conditions on a regular basis.

STEP 1

To grease TOTAL CHAOS control arms on the vehicle, it is not mandatory to have the vehicle jacked up with the wheel off, although it will make the process much easier.

STEP 2

First you **MUST** loosen the through-bolt holding the bushings together. This opens an area for the grease to expand when being pumped into the zerk fittings. Loosen, but do not fully remove the nut from the bolt.




STEP 4

If you do not loosen the bolt, the grease being pumped into the bushing has nowhere to go. The pressure will cause the bushing to mushroom and be destroyed. If you see the bushing start to deform, immediately stop pumping in grease, grab a small pick, and push in the ball on the zerk fitting to release the excess pressure.



STEP 3

With the bolt loose, pump grease into the zerk fitting until you can see the excess grease bleed out from between the bushing "hat" and the plated end washer (yellow arrow).



STEP 4

Torque the nut to factory spec and wipe away any excess grease from around the bushings.



RECOMMENDED ALIGNMENT PROCEDURE

All vehicles equipped with TOTAL CHAOS suspension systems should be taken to an alignment shop that is familiar with off-road suspension systems.

There is increased caster angle built into most TOTAL CHAOS suspension systems. When setting alignment, camber and toe should be set as close to factory spec as possible. Caster will usually be higher than factory specifications. Attempting to bring caster to factory spec will likely result in camber and toe being out of factory specifications, which will result in poor drivability and uneven tire wear. The caster that is built into TOTAL CHAOS suspension systems is sufficient, attempting to add excessive caster into the alignment may result in the inability to adjust camber and toe.

Alignment specifications will vary depending upon:

- Vehicle model
- Suspension kit purchased
- Prior vehicle modifications
- Desired coilover spring pre-load and or ride height

TOTAL CHAOS' suspension products are designed to align with aftermarket shocks that are set to the recommended amount of lift. Some vehicles may not correctly align if the ride height is altered from the recommended settings. If you have followed all of the instructions and the vehicle still won't align correctly, it's likely that there is something installed wrong, or the frame mounting points and/or knuckles may be bent or damaged.

Frequently Asked Questions & Important Things To Read About TC Equipment and Parts

UNIBALLS

TC uses a 100% stainless steel uniball and race for maximum corrosion resistance in all our equipment. The uniballs feature a military grade PTFE Liner that makes much less noise than the standard lined uniballs used in competing brands. This military grade PTFE liner is self-lubricating and does not require any additional lubrication or grease. If you have a ball that is making some noise apply either a layer of Tri-Flow Superior Dry Lubricant (No. TF21013) or CRC Dry PTFE Lube (No. 03044). Uniballs are a consumable item and will need to be replaced when the military grade PTFE Liner wears away. Grabbing your wheel and applying force to see if the ball is moving in the race will determine their maintenance schedule. Each uniball is retained in the uniball cup at the end of the arm with a large snap ring. Wiping the uniballs down with a damp cloth to remove any built up dirt and debris will help extend the life of these parts Replacement parts are available directly from TOTAL CHAOS Fabrication Inc.

POLYURETHANE BUSHINGS

Poly bushings can and will make some noise. They offer many benefits vs. a factory style rubber bushing. To reduce as much noise as possible, TC uses a synthetic grease that contains PTFE called Superlube (No. 41150). If Superlube is not readily available use a good synthetic grease (Mobil 1, Valvoline, etc.).When greasing your pivot bushings on the vehicle it is very important not to force too much grease into the zerk fittings. This will cause excess pressure to become trapped in the pivot and will result in mushrooming the bushing shoulders out of the pivots. To prevent this, first loosen the factory bolt that holds the arms to the frame and separate the washers from the face of the bushings when applicable. This will allow any excess pressure and grease to escape. Don't forget to re-torque the factory bolt when you are finished to a factory torque specification!

ZERK FITTINGS

The grease nipples or zerk fittings that are supplied with our arms are ¼"-28 in size. Should you have a tapped hole that has an excess amount of powder coat in it, use a ¼"-28 tap to clean it up. When installing the zerk fittings take care not to over tighten them as they are hollow and can snap off. When fully installed they will not sit all of the way flush with the pivot, just insert them two or three rotations until they are snug. Don't forget to have them pointing in the right direction so you can get a grease gun onto them once the arms are installed onto the vehicle.

ANTI-SIEZE

To aid in future disassembly of components, we recommend that you liberally apply an anti-seize to all metal on metal contact surfaces such as the ID of the uniball, hi-mis spacers, and inner sleeves. Also, apply it to the threads on any C-lock or Stover nut. This will prevent the C-lock portion of the nut from galling onto the bolt.

BLACK OXIDE COATED PARTS

Some components (such as 4340 axle shafts and lower uniball conversion cups) are coated with Black Oxide. While this will help to prevent rust, depending on your climate you may want to further coat these parts. For axle shafts we wrap a layer of electrical tape the length of the shaft (excluding the splines). For lower uniball conversion cups you can use black spray paint, just be sure to mask of the uniball before painting.

HARDWARE TORQUE

All hardware should be re-torqued after an initial break in period of 50 miles and again at 500 miles. Periodically after that you should inspect your suspension to ensure that nothing is loose, worn, or damaged.

UNIBALL CAPS

We do not use any sort of cap or cover over our uniballs as these actually lead to premature wear and corrosion. With a cap installed moisture and containments work their way up through the underside of the uniball and then become trapped. With no cover this moisture can evaporate and you have easy access to wipe down the uniball periodically.

WARNING

TOTAL CHAOS FABRICATION's aftermarket suspension products and accessories modify a vehicle for uses which exceed conditions anticipated by the vehicle manufacturer. The uses include the high-performance demands required during off-road. These conditions vary in the degree of severity and cannot be controlled by the vehicle or product manufacturer. If the components within the suspension system or accessories become worn due to frequent on-road and/or extreme off-road use, the safety and reliability of the vehicle is at risk. The maintenance of aftermarket equipment to ensure the vehicle occupants safety is entirely your responsibility. Do not purchase TOTAL CHAOS manufactured products or components unless you are willing to accept this responsibility. Do not install any TOTAL CHAOS suspension products or accessories unless you are certified and/or competent at installing the product without causing present or future injury to yourself or other vehicle occupants, other vehicles and their occupants, pedestrians and motorcyclists; seek an authorized installation center.

TOTAL CHAOS FABRICATION long travel suspension systems were designed for off-road use only. This suspension system is not to be modified from its original design in any way. TOTAL CHAOS is not liable nor held responsible for any injury's or death that can occur from off-road use or as the result of product failure. Customer/driver assumes all liability in assuring that the suspension system is properly installed, maintained, and operating in safe conditions. The following are guidelines for maintaining a safe operating vehicle. Safety and reliability are our number one concern.

Visually inspect all equipment for clearance and unusual wear.

Regularly clean and inspect equipment such as suspension components, heim joints, polyurethane bushings and all hardware. Replace items as necessary. All suspension components are available for individual replacement direct from TOTAL CHAOS. We strongly recommend the suspension system be installed by an authorized installation center. TOTAL CHAOS FABRICATION reserves the right to warranty any components that we have determined to be product or material defective. Off-road abuse can damage suspension components.


BREAK IN PERIOD. After every installation we recommend checking the torque of all nuts and bolts to assure that the torque has taken after driving 500 miles. Some minor adjustments may need to be made.

The customer assumes all responsibility for the use of all equipment and the proper maintenance of said equipment. This equipment will alter the center of gravity of your vehicle and also the handling characteristics that you may be accustomed to. Even though your vehicle may have a wider track width it is capable of rolling over. Please wear your seat belt and demand that all passengers do so as well.

Please remember that no matter how well your vehicle is built it is only as safe as you drive it. This equipment is designed to improve the performance of your vehicle. **INCREASING PERFORMANCE ALSO INCREASES YOUR RISK WHILE OPERATING THIS VEHICLE.** The operator must know and understand the vehicles handling characteristics. None of this equipment is guaranteed to be free of defect or to protect the driver or occupants from death or injury in the event of a collision. Please drive in a safe and sane manner.



INSTALLATION INSTRUCTIONS



**COMPONENT: KING 3.0 COILOVER REMOTE
RESERVOIR BRACKETS**

**2010-2023 LEXUS GX 460
2010-2023 TOYOTA 4RUNNER**

PART #: 48655

PART #	DESCRIPTION	QUANTITY
48655-LASER	KING 3.0 COILOVER SHOCK CUSTOM RESERVOIR BRACKETS	2
12504	WASHER: 7/16" SAE (GOLD ZINC)	4
11501	NUT: 7/16" - 20 NYLOCK (ZINC)	2
10518	BOLT: 7/16" - 20 X 4" GRADE 8	2
12022	WASHER: 8MM FLANGE WASHER	2
11085	PEM NUT: 8MM - 1.25	1
10825	BOLT: 8MM - 1.25 X 25MM L GRADE 10.9 FLANGE HEAD (ZINC)	2

REQUIRED TOOLS

- 5/8" Wrench or Socket
- 13mm Wrench or Socket
- 3/16" Allen Wrench
- Cutting Wheel
- Sanding Disc
- Anti-Seize
- Spray Paint

IMPORTANT

- Before starting install, make sure the vehicle is supported securely on jack stands.
- Basic cutting/grinding required.

STEP 1

Remove the rectangular plastic plug on the side of the frame rail to gain access to the inside of the frame.

**STEP 2****Passenger Side Only:**

Using the provided 8mm PEM® nut put the nut on the end of your finger, through the access hole and slide it along the inside of the frame rail until it lines up with the round hole just in front of the access hole.



STEP 3

Use the provided 8mm 1.25 bolt to screw into the PEM® nut. Once the nut is snug and centered in the round hole use a wrench and tighten the bolt. When you tighten the bolt the splines on the nut will bite into the frame and the nut will now be wedged into the hole so the nut will not have to be held with a wrench.



STEP 4

In the passenger fenderwell, remove the pointed windshield washer fluid reservoir shield. Trimming is required in order for the coilover reservoir to fit properly.



STEP 5

Mark a small rectangle around the point of the shield and use as a guide for trimming.



STEP 6

Use the (2) ¼"-20 button head bolts (included with the shocks) to secure the reservoir to the bracket. Note: these are stainless steel bolts threading into aluminum, we advise using anti seize.

Note: The reservoir brackets are stamped L for left and R for right. Those stampings are on the inside of the bracket facing the frame.



STEP 7

Use the 7/16" bolt to go through the washer, bracket, and through the entire frame then install the nut and washer on the inside of the frame rail.

**STEP 8**

Use the 8mm bolt and secure the rear bracket hole to the frame threading into the pre-installed PEM nut on the passenger side, and into the factory threaded hole on the driver's side.



STEP 9

Before tightening the reservoir clamp, make sure that the reservoir hose routing is correct and not in danger of contacting any part of the vehicle that may damage the hose.

Use the 1/4"-20 socket head bolt to tighten the clamp which will squeeze the reservoir.

Note: These are stainless bolts threading into aluminum, we suggest using anti-seize.



STEP 10

Reinstall the plastic rectangular frame plug and ensure that all bolts are tight and the reservoir is secure.



STEP 11

On the driver's side, the rear 8mm x 1.25 bolt pinches down the KDSS bracket and threads into the frame without a PEM nut.

On non-KDSS models the bolt will thread into the same hole in the frame.



For NON-KDSS models, you will need to trim the KING reservoir bracket to properly lower the factory sway bar. The following steps explain the process.

STEP 12

Begin by marking the three welds that connect the base to the upright.



STEP 13

Place the mount in a vice. Using a cutting wheel, lightly cut through the three welded spots.



STEP 14

Once the three welded spots are ground through, lightly strike the upright to remove it from the base.

**STEP 15**

Sand down any remaining rough edges.



STEP 16

Paint the base with a protective coating such as Steel-It, Rustoleum, or something similar.

**STEP 17**

Mount the spacer to the underside of the frame using the supplied (from KING) allen bolts.



STEP 18

Using the zinc-plated bolts supplied by KING, mount the factory sway bar in the two remaining holes on the spacer.



INSTALLED PHOTOS:

Driver Side Fenderwell - Non-KDSS



Driver Side Fenderwell - With KDSS

CONGRATS! YOU'RE READY TO GO!

**FOR INSTALL QUESTIONS OR CUSTOMER SERVICE INQUIRIES:**Call 951.737.9682 or email info@chaosfab.com